

Thank you for choosing our product. Your choice is our motivation to improve. Please read this manual carefully before using the product to ensure you master it quickly. If you have any questions, please feel free to contact us.

INSTRUCTIONS:

Sealing Function

1. Please remove the hook before using our product.
2. Our product uses a USB cable for charging, so the battery can be used.
3. Press the "on" button for 2 seconds to turn on the power. The white indicator light will turn on.
4. When the power is turned on, use the sealing function to seal the bag. Place the bag on the front-end sealing machine, where the location of the "U" type clamp mouth is, then press the "+" key according to the thickness of the plastic bag (thin speed bag with fast, slowing down of the bag when thick).
5. If you need to use it again, press the button to restart. After three minutes, the device will automatically turn off.

Vacuum Function

1. Press for 2 seconds to turn on the power, and the white light will turn on.
2. Press the key again, the orange light will turn on, and the vacuum function will start at the bottom. The design of our product is suitable for manual vacuum silica gel suction nozzle (no accessories needed) which can be directly aligned with the suction hole of various types of storage bags.
3. Press the button again to turn off the power, or the device will automatically shut off after 3 minutes.

Inflation Function

1. Press the power button for 2 seconds to turn on, and the power indicator light will turn white.
2. Press the key once again, the orange light will turn on, and the inflatable function will be activated. The inflatable device is inserted with the inflatable needle accessories.
3. Press the power button again. After 3 minutes, the main power supply will be cut off automatically.

Bag Opening Function

Place the bag to be unsealed into the "U" port, then press the "-" button and pull the bag left or right to unseal it (use a double-sided knife).

Before the use of this product, the hook needs to be removed first, after use, put the hook into the designated slot, and then you can hang it for storage to save kitchen space.

This product contains accessories:


2 flat bags, 2 vacuum bags, 1 ball needle, 1 air nozzle, 1 charging wire

WARNING:

1. This product is suitable for adults, children should be accompanied by an adult.
2. Do not clean the product with water.
3. Storage of this product is prohibited above 50 degrees Celsius.
4. Keep the product away from flammable and explosive materials.
5. This product has a built-in blade. Children must be accompanied by an adult to use it.
6. If the product is not used for more than 3 minutes, the power supply will automatically shut off.
7. This product uses a 1A 5V charger.
8. Fast chargers are strictly prohibited.

SPECIFICATION:

- | | |
|-----------------------|------------------------------|
| ● Weight: 142g | ● Size: 417mm x 171 mm |
| ● Voltage: 5V | ● Inflation Pressure: 100KPA |
| ● Motor Power: 6W | ● Vacuum Pressure: -65KPA |
| ● Heating Power: 6.5W | ● Battery Capacity: 800mAH |



Distributed by:



IDEAL WORLD
PO Box 443, Feltham TW13 9DU
Email: customercare@idealworld.tv
Tel : 0800 151 2345
Web: www.idealworld.tv

MADE IN CHINA

homesmart®



PORTABLE ELECTRIC AIR PUMP

USER MANUAL